



ASSEMBLY INSTRUCTIONS

TITIAN DESK MODEL# 86154ATOB-01-KD-U Sears# 15397






Front view

Back view



PARTS IDENTIFICATION

ITEM	DESCRIPTION	QTY
#1	TOP PANEL	01
#2	LEFT SIDE	01
#3	RIGHT SIDE	01
#4	BACK PANEL	01
#5	BOTTOM FRAME	01
#6	BACK RAIL	01
#7	LEFT VERTICAL BOARD	01
#8	RIGHT VERTICAL BOARD	01
#9	LEFT CROSS BAR	01
#10	RIGHT CROSS BAR	01
#11	DRAWER FRONT	01
#12	LEFT DRAWER SIDE	01
#13	RIGHT DRAWER SIDE	01
#14	DRAWER BACK	01
#15	DRAWER BOTTOM	01






HARDWARE IDENTIFICATION

Please line up the hardware with the correct full size image to make sure you are installing the hardware correctly.

ITEM	PICTURE		DESCRIPTION	QTY
A		(Ø4) Not to Scale	LARGE BOLT	02
В		Not to Scale	KNOB	02
С	(+)	(Ø3.5x25mm) Not to Scale	SCREW	80
D		(Ø8x30mm) Full Size	WOOD DOWEL	30
E		(Ø4x30mm) Full Size	SCREW	42
F	(†) (†)/////////////////////////////////	(Ø3x15mm) Full Size	SCREW	14

Tools required







Small hammer










STEP 2.


knocking the wooden dowels tight by hammer



IMPORTANT:

- 1. DO NOT TIGHTEN BOLTS COMPLETELY UNTIL ALL BOLTS ARE COMPLETELY LINED UP AND INSERTED INTO HOLES / NUTS.
- 2. DO NOT OVER TIGHTEN SCREWS AND BOLTS TO AVOID STRIPPING.





knocking the wooden dowels tight by hammer

